

AMK Air pump

Tactical Relocation Bracket

Installation instructions for the Tactical 4x4 AMK air pump relocation bracket.

***Please read through all instructions before beginning installation.

1. First remove the lower plastic cover, which is secured with 10 mm bolts and flexible tabs.
2. Remove the three pump feet using a torx driver. This will allow you to lift up the pump and remove the rubber bushings and spring assemblies. (bushings and springs will later be put back into same position using T44 bracket)
3. Using bungee cords, suspend the pump above the stock bracket so the bracket can be removed.
4. Bracket is attached to the frame with three 10mm bolts. Remove bolts and set stock bracket aside.
5. Using the three stock bolts that you just removed, loosely attach the T44 AMK Pump Relocation Bracket where the stock bracket was removed.
6. Replace the three rubber bushings and springs in the same configuration that they were removed.
7. Remove bungee cords and position pump back onto the spring loaded feet and replace torx bolts that were removed earlier.
8. Gently slide the bracket up as far as it will go and tighten the three 10mm bolts that secure it to the frame.
9. You are now ready to install the T44 rock sliders.

For technical support please contact Tactical 4x4 via e-mail at info@tacticalrovers.com or by phone (951)239-6236

Best regards,

Tactical 4x4, *Giving you the Tactical Advantage!*